



**PLATINUM**  
VISUAL SYSTEMS

## SDS / INSTALLATION INSTRUCTIONS: SLIDING DISPLAY CASE INSTALLATION

### SDS INSTALLATION INSTRUCTIONS:

1. CLEAN OPENING BEFORE INSTALLING SDS UNIT AND MAKE SURE THERE ISN'T ANY DEBRIS OF ANY KIND.
2. ANY UNIT(S) EXCEEDING 6'-0" IN LENGTH, IS RECOMMENDED THAT YOU INSTALL THIS UNIT WITH AN ADDITIONAL PERSON IT COULD BE A LITTLE TOO HEAVY TO LIFT FOR A SINGLE PERSON.
3. SLIDE UNIT INTO OPENING VERY GENTLE UNTIL IT TOUCHES THE BACK OF THE OPENING.
4. ONCE THE UNIT IS INSIDE THE OPENING PREPARE TO ANCHOR THE UNIT BY ANCHORING THE TOP PORTION OF THE UNIT AT ABOUT 2" FROM THE TOP DOWN, USE A #8-2" SCREW AND ANCHOR THROUGH THE STANDARD FOR SHELVES.
5. PREPARE TO ANCHOR THE BOTTOM USING SAME TYPE OF SCREW #8- 2" AT ABOUT 2" FROM THE BOTTOM UP. (SEE DRAWING).
6. ONCE THE CASE HAS BEEN PROPERLY INSTALLED, HANG THE SHELF BRACKETS ON THE STANDARDS AND HANG ON DESIRED LOCATION HEIGHT.
7. ONCE ALL GLASS SHELF BRACKETS ARE IN PLACE PREPARE TO OUT THE GLASS SHELVES.
8. LAST STEP SLIDE GLASS DOORS INTO TOP CHANNEL AND DO THE SECOND TRACK FIRST AND THE SECOND TRACK. ONCE ALL GLASS DOORS HAVE BEEN PROPERLY INSTALLED.
9. CLEAN GLASS WITH WINDOW CLEANER OR WINDEX, AND UNIT IS READY FOR USE.
10. NOTE: UNIT(S) WITH LIGHTS CHECK PLANS, OR CONTACT GENERAL CONTRACTOR FOR SPECIFIC WIRING AND CONNECTIONS.

