



PLATINUM[™]

VISUAL SYSTEMS

CARE AND MAINTENANCE

DISPLAY CASES / BULLETIN CASES

Daily Care and Cleaning

Wipe aluminum finishes with a clean cloth moistened with a non-ammonia based glass cleaner then rinse with clean water. Wipe dry with a clean dry cloth.

Special Cleaning for aluminum finishes and glass

To remove, grease and other miscellaneous stains, dampen a clean cloth with water and sprinkle a small amount of powder cleanser on the cloth. Begin cleaning a small area with a back and forth horizontal motion using normal pressure as if cleaning a window. Wipe off the residues with a dry cloth then rinse with clear water. Wipe dry with a clean, dry cloth. Repeat if necessary. Another alternative cleaner is simple green for all aluminum finishes and window cleaner or windex for all glass windows and shelves.

Wood veneer box Cleaning

Veneer box / (top, bottom and sides) use a damp cloth to clean dirt and dust. Cleaner designed to clean wood finishes are acceptable. Do not use solvent base cleaners as this will damage the veneer box.

FIXED BACK PANEL TACKABLE SURFACES

Natural Corkboard

A mild soap and water solution is recommended for normal cleaning. If a more thorough cleaning is required the use of a pH neutral cleanser is recommended. Rinse with clean water, then dry with an absorbent cloth. Examine dried area and repeat if necessary.

Vinyl Corkboard and Tackboard

Stains should be removed as quickly as possible to eliminate any possible reaction between the staining agent and the vinyl. Excess soiling such as chewing gum, crayons, paint or nail polish should be carefully scraped off prior to other cleaning steps. Normal cleaning of Vinyl Corkboard and Tackboard should be done with a mild soap and water solution. If stronger cleaning is required the use of a liquid household cleaner is recommended. Rinse with clean water, then dry with an absorbent cloth. Examine dried area and repeat if necessary.

Fine Grain Colored Corkboard

Clean with a mild soap and water solution to retain its original appearance and freshness. If stronger cleaning is required, the use of a pH neutral cleanser is recommended. Rinse with clean water, then dry with an absorbent cloth. Examine dried area and repeat if necessary.

Fabric Corkboard and Tackboard

Stains should be removed as quickly as possible to eliminate any possible reaction between the staining agent and the fabric. To prevent overall soiling, frequent vacuuming or light brushing to remove dust and dirt is recommended. Sponge clean dirt spots with a mild detergent or upholstery cleaner. Using a blotting technique, without rubbing, should sufficiently remove most spots. Rinse well with a clean sponge to remove any cleaning solution. A professional furniture cleaning service is recommended for excessive soiling.