




PLATINUM
VISUAL SYSTEMS



FASTENER SIZE PER MANUFACTURER RECOMMENDATION
#8 FASTENER IS SUFFICIENT.


WTS / INSTALLATION INSTRUCTIONS: CHALK/MARKERBOARD INSTALLATION

WTS DROP IN BOX TRAY SYSTEM / INSTALLATION INSTRUCTIONS:

1. DISTRIBUTE BOARDS TO THEIR SPECIFIED LOCATIONS.
2. DETERMINE LOCATION AND MOUNTING HEIGHT ABOVE FINISH FLOOR.
3. LOCATE SPECIFIED AREA ON WALL FOR BOARD LOCATION. DETERMINE LOCATION AND MOUNTING HEIGHT ABOVE FINISH FLOOR. LOCATE SPECIFIED AREA IN WALL FOR BOARD LOCATION. ESTABLISH HORIZONTAL LOCATION OF BOARD. USING EITHER SIDE OF BOARD LOCATION AS A STARTING POINT (RIGHT OR LEFT), MEASURE UP FROM FLOOR IN ACCORDANCE WITH SPECIFIED MOUNTING HEIGHT AND MARK WALL. (THIS IS DONE ONLY TO GAIN A ROUGH ESTIMATE MOUNTING HEIGHT. MEASURE DOWN FROM CEILING TO THE SAME POINT AND MARK WALL TO ESTABLISH ACCURATE MOUNTING HEIGHT. (THIS STEP IS NECESSARY AS FLOOR IS NOT ALWAYS LEVEL. WITH ACCURATE STARTING POINT ESTABLISH, MEASURE UP 3 1/2" AND MARK WALL. THIS MARK WILL REPRESENT LANDMARK FOR LEVEL LINE TO BE USE AS A GUIDE DURING INSTALLATION OF CR340 MARKER/CHALKTRAY. WITH BOARD WIDTH IN MIND, REPEAT PREVIOUS STEP ON OPPOSITE SIDE OF BOARD LOCATION. SNAP CHALK LINE FROM BOTH POINTS ESTABLISHED AND CHECK LINE FOR LEVEL. IF LINE IS LEVEL PROCEED.
4. INSTALLING THE MARKER/CHALK TRAY TO THE WALL. USING A "STUD FINDER" OR OTHER AVAILABLE MEANS LOCATE STUDS ALONG LEVEL LINE. MARK LOCATION OF STUDS ON LEVEL LINE. MAKE MARKS LONG ENOUGH AS YOU USE THESE MARKS VISUALLY TO ACCURACY TRANSFER LOCATIONS TO TRAY. PLACE THE CR340 MARKER/CHALK TRAY ON WALL AND TRANSFER ALL STUD LOCATIONS TO BACK LEG OF TRAY. REMOVE TRAY FROM WALL AND DRILL A 3/16" [.1875] Ø HOLE AT EACH LOCATION. COUNTERSINK THE HOLES JUST DRILLED. THIS STEP IS NECESSARY TO ENSURE ANY AND ALL FASTENERS DO NOT INTERFERE WITH BOARD WHEN PLACE IN THE TRAY. PLACE TRAY BACK ON WALL, MOUNT SECURELY TO STUDS ENSURING AT LEAST 1" STUD PENETRATION.



PLATINUM
VISUAL SYSTEMS



FASTENER SIZE PER MANUFACTURER RECOMMENDATION
#8 FASTENER IS SUFFICIENT.

WTS / INSTALLATION INSTRUCTIONS: CHALK/MARKERBOARD INSTALLATION

WTS DROP IN BOX TRAY SYSTEM / INSTALLATION INSTRUCTIONS:


5. MOUNTING BOARD TO WALL: A) APPLY MANUFACTURER ADHESIVE TO BACK OF BOARD USING DOBBING OR BEADING METHOD. NOTE: DEPENDING ON THE WALL AND FIELD CONDITIONS THE ABOVE STEP MAY NOT BE NECESSARY. IF THIS IS THE CASE AND OR THE CONDITIONS ARE NOT CLEAR TO YOU, CONTACT THE MANUFACTURER IMMEDIATELY.

6. INSERTING PANEL INTO CR315 TRAY: A) PUSH TOP OF PANEL AGAINST WALL, DEPENDING ON THE SIZE AND OR CONFIGURATION OF BOARD THIS STEP MAY REQUIRE THE NEED FOR ADDITIONAL MANPOWER. B) BEGINNING AT EITHER SIDE OF BOARD, PUSH MOUNTING CLIP DOWNWARD UNTIL IT TOUCHES TRIM ONM TOP OF BOARD AND FASTEN WITH $\frac{5}{8}$ " TRUSS HEAD SCREW SUPPLIED BY MANUFACTURER.C) REPEAT ABOVE STEP FOR ALL REMAINING MOUNTING CLIPS.

7. PREPARE BOARD FOR USE: BLOW OFF ANY DUST OR DEBRIS FROM INSTALLATION AND CLEAN SURFACE OF MARKERBOARD AS NEEDED TO A READY FOR USE CONDITION.



PLATINUM
VISUAL SYSTEMS



FASTENER SIZE PER MANUFACTURER RECOMMENDATION
#8 FASTENER IS SUFFICIENT.

FINISHED FLOOR

PER PLANS

WTS / INSTALLATION INSTRUCTIONS: TACKBOARD INSTALLATION

WTS INSTALLATION INSTRUCTIONS:

1. DISTRIBUTE BOARDS TO THEIR SPECIFIED LOCATIONS.
2. DETERMINE LOCATION AND MOUNTING HEIGHT ABOVE FINISH FLOOR.
3. LOCATE SPECIFIED AREA ON WALL FOR BOARD LOCATION. DETERMINE LOCATION AND MOUNTING HEIGHT ABOVE FINISH FLOOR. LOCATE SPECIFIED AREA IN WALL FOR BOARD LOCATION. ESTABLISH HORIZONTAL LOCATION OF BOARD. USING EITHER SIDE OF BOARD LOCATION AS A STARTING POINT (RIGHT OR LEFT), MEASURE UP FROM FLOOR IN ACCORDANCE WITH SPECIFIED MOUNTING HEIGHT AND MARK WALL. (THIS IS DONE ONLY TO GAIN A ROUGH ESTIMATE MOUNTING HEIGHT. MEASURE DOWN FROM CEILING TO THE SAME POINT AND MARK WALL TO ESTABLISH ACCURATE MOUNTING HEIGHT. (THIS STEP IS NECESSARY AS FLOOR IS NOT ALWAYS LEVEL. WITH ACCURATE STARTING POINT ESTABLISH, MEASURE UP 3 1/2" AND MARK WALL. THIS MARK WILL REPRESENT LANDMARK FOR LEVEL LINE TO BE USE AS A GUIDE DURING INSTALLATION OF L-CLIP. WITH BOARD WIDTH IN MIND, REPEAT PREVIOUS STEP ON OPPOSITE SIDE OF BOARD LOCATION. SNAP CHALK LINE FROM BOTH POINTS ESTABLISHED AND CHECK LINE FOR LEVEL. IF LINE IS LEVEL PROCEED.
4. INSTALLING TOP L-CLIPS TO THE WALL. USING A " STUD FINDER" OR OTHER AVAILABLE MEANS LOCATE STUDS ALONG LEVEL LINE. MARK LOCATION OF STUDS ON LEVEL LINE. MAKE MARKS LONG ENOUGH AS YOU USE THESE MARKS VISUALLY TO ACCURACY TRANSFER LOCATIONS TO L-CLIP. PLACE THE L-CLIP ON WALL AND TRANSFER ALL STUD LOCATIONS TO THE REST OF L-CLIPS. PLACE L-CLIP BACK ON WALL, MOUNT SECURELY TO STUDS ENSURING AT LEAST 1" STUD PENETRATION.
5. PREPARE BOARD FOR USE: BLOW OFF ANY DUST OR DEBRIS FROM INSTALLATION AND CLEAN SURFACE OR MARKERBOARD AS NEEDED TO A READY FOR USE CONDITION.